

# HOW TO FIT GENIEGRIPS® CUSHIONS



## STEP 1:

### Locate Magnets

Ensure Cushions are correct way up, with magnets facing forktyne shaft.

## STEP 2:

### Position Cushion

Position the Cushions over the forktyne so it meets the top of shaft.

## STEP 3:

### Push Firmly

Push Cushions firmly against the forktyne shaft to ensure strong contact is made with magnets.



## STEP 4:

### To Remove

Reverse steps 1-3 to remove GenieGrips® Cushions.

## STEP 5:

### Storage

Store Cushions away neatly on forklift to ensure GenieGrips® are easily accessible at all times.

**WARNING** Magnets may interfere with the function of cardiac pacemakers and implantable cardioverter-defibrillators (ICDs). Do not place the GenieGrips® Cushions near your chest if you have a cardiac pacemaker or ICD.



### ALWAYS:

- Ensure forklift truck is only operated by licensed/trained personnel and in accordance with manufacturer's safe operating procedures.

### HELPFUL HINT:

*"Ensure GenieGrips® Cushions magnets are kept clean and free of contamination (eg grease, oil, paint, etc)"*